

Alleima® 5R62/3R65 medical wire

Wire

Datasheet

Alleima® 5R62 and Alleima® 3R65 are austenitic stainless steels alloyed with molybdenum. Alleima® 3R65 is a low carbon version of Alleima® 5R62.

The grades are characterized by:

- Good resistance to general corrosion and better resistance to pitting than ASTM 304, because of the alloying with Mo
- High tensile strength

Standards

- ASTM: 316/316L
- UNS: S31600/ S31603
- ISO: 316/316L
- EN Number: 1.4401/1.4404
- EN Name: X5CrNiMo17-12-2/X2CrNiMo17-12-2
- W.Nr.: 1.4401/1.4404
- JIS: SUS316/SUS316L

Product Standards

- ASTM F899
- ISO 16061

Applications

Alleima® 5R62 and Alleima® 3R65 are mainly used for medical and dental tools.

Chemical composition (nominal) %

Alleima® 5R62	≤0.06	≤0.7	≤1.8	17	11.0	2.3
Alleima® 3R65	≤0.03	≤0.7	≤1.8	17	11.5	2.3

Forms of supply

Wire form

- In coils with weights up to 150 kg
- On various types of spool with wire weights up to 500 kg
- In straightened lengths up to 4 m

Surface finishes and size range

Surface finish	Size range, mm
Coated	0.23 - 8.00
Bright	0.15 - 0.80
Mechanically polished	0.40 - 6.00

Mechanical properties

Typical mechanical properties for Alleima® 5R62 and Alleima® 3R65 at 20°C.

Grade	Tensile strength		Proof strength	Elongation	Hardness
	Rm		Rp _{0.2}		
	MPa	MPa	%	HRB	HB
Alleima® 5R62	≥515	≥205	≥40	≤95	≤217
Alleima® 3R65	≥485	≥170	≥40	≤95	≤217

Physical properties

Typical physical properties for annealed Alleima® 5R62 and Alleima® 3R65 are given below:

Grade	Density	Elastic Modulus	Mean Coefficient of Thermal Expansion	Thermal Conductivity	Specific Heat	Resistivity
	g/cm ³	10 ³ MPa	mm/m/°C	W/m °C	J/kg °C	μΩm
			0-100 °C	at 100 °C	0-100 °C	20 °C
Alleima® 5R62/3R65	8	193	16	16	500	0.74

Corrosion resistance

Excellent corrosion resistance in a range of atmospheric environments and various corrosive media.

Subject to pitting and crevice corrosion in warm chloride media and to stress corrosion cracking at temperatures above around 60°C.

Considered resistant to potable water with up to approximately 1000 mg/l chlorides, at ambient temperatures, reducing to approximately 500 mg/l, at 60°C.

Disclaimer:

Alleima is not providing any products or services that are intended or may be construed to be recommending or otherwise advising on, in any manner, the design, suitability, appropriateness or effectiveness, from a medical/biological/safety perspective, of any medical material, instrument and/or medical device.